


## NANO RECORDERS NR-2025, NR-2032 manual



### BATTERY:

Insert battery CR2025 ( for NR-2025 model ) or CR2032 ( for NR-2032 model). Battery negative need to be faced UP, look at picture above.

When need to remove battery from recorder, use battery removal PIN supplied with device

Please use high quality batteries for maximum performance, Duracell and GP are recommended

### TO CHECK RECORDER STATUS:

- \* Short press ON-OFF button : LED blink RED – device is in OFF state
- LED blink GREEN – device is in recording state

### TO TURN RECORDER ON :

- \* Press ON-OFF button for 3 seconds, LED will blink GREEN 7 times, device is now recording

### TO TURN RECORDER OFF:

- \* Press ON-OFF button for 3 seconds, LED will blink RED for 7 times, device is now in OFF state

### TO CONNECT WITH PC:

- \* Connect recorder with PC via supplied USB cable and continue with PC software manual

### TECHNICAL SPECIFICATIONS:

	<b>NR-2025</b> RECORDING/ STANDBY (HOURS)	<b>NR-2032</b> RECORDING/ STANDBY (HOURS)
<b>BEST QUALITY</b> (22kHz, A-LAW)	35/43	51/64
<b>BEST PERFORMANCE I</b> (16kHz, PCM)	38/320	38/530
<b>BEST PERFORMANCE II</b> (11kHz, ADPCM)	44/400	66/600
<b>BEST DURATION</b> (8kHz, ADPCM)	55/400	90/600
<b>SLEEP MODE</b> (SCHEDULE ON)	3200	4800
<b>DIMENSIONS</b>	31*22*8 mm	27*23*12 mm
<b>BATTERY</b>	DURACELL CR2025 (160mAh)	DURACELL CR2032 (240mAh)